Maintenance

Harken equipment requires minimal maintenance, but some is required to give the best service and to comply with Harken's limited warranty.

Keep equipment clean by frequent flushing with fresh water. Periodically clean with mild detergent and water solution. Spin sheaves to distribute soap solution evenly.

In corrosive atmospheres, stainless parts may show discoloration around holes, rivets and screws. This is not serious and may be removed with a fine abrasive.

IMPORTANT! Exposure to some teak cleaners and other caustic solutions can result in discoloration of part and is not covered under the Harken warranty.

Warranty

For additional safety, maintenance and warranty information see www.harken.com/manuals or the Harken® catalog.

W15W24988 Bluemound Rd. • Pewaukee, WI 53072 U.S.A.
Telephone: (262) 691-3320 • Fax: (262) 701-5380
Web: www.harken.com • Email: harken@harken.com

Printed in U.S.A. 4623 04/14

HARKEN®

INSTRUCTION SHEET

Flip-Flop Blocks
2142, 2143, 2144, 2145, 2678, 2679, 2688, 2689

Strictly follow all instructions to avoid an accident, damage to your vessel, personal injury or death. See www.harken.com/manuals for additional safety information.





Mount using ends to mark drill holes. Make sure they are square and against sheave assembly.

Use all four (4) fasteners with backing plates, washers and locknuts. Deck or mounting surface must solid, designed for block load. Consult with builder.

Mount with 4 (SH) Sockethead Cap or (PH) Panhead Screws	
2142, 2143, 2144, 2145	#10 (5 mm)
2678, 2679, 2688, 2689	1/4" (6 mm)