Wichard, 1 ZI de Felet, CS 50085, 63307 Thiers, France
Tél: +33 (0)4 73 51 65 00 — E-mail: marine@wichard.com

Babystay tang - For 6 to 10 mm wire

Part #9150



Description

Accessories to set up a babystay adjuster
To be fitted to the mast (by driling a hole: 7 * 100 mm)
For 6 to 10 mm dia wire

Applications

Installation of a babystay adjuster with wheel

Technical information

Materials	316L stainless steel grade
Weight (g)	306

Caption

Working load (WL) : for nautical applications

Working Load Limit (WLL): for industrial applications only.
The safety factor is 5 times the breaking load.
WLL = Breaking load / 5

Wichard strives to ensure, to the best of its ability, the accuracy and the update of the information disseminated on this document, and reserves the right to correct at any time and without notice the content, as well as to evolve its products.

In the case of an industrial application, please contact our sales and technical department to validate the use of these products. The request for certificates can be made directly with the sales department when ordering the products.

Non-contractual pictures.

© Wichard 2026